



CCD READER

Software Configuration Manual



CCD READER

SOFTWARE CONFIGURATION MANUAL

CONTENTS

HOW TO USE THIS MANUAL	v
INTRODUCTION.....	1
STATUS INDICATORS	1
RESET FACTORY DEFAULT	2
CONFIGURATION	2
RS232	3
Baud Rate.....	3
Parity.....	4
Data Bits	4
Stop Bits	4
Ack/Nack Protocol	5
Handshaking.....	5
Inter-Character Delay	7
FIFO.....	7
RX Timeout	8
WEDGE	9
Keyboard Nationality	11
Caps Lock.....	12
Inter-Character Delay	12
Inter-Code Delay	12
WAND EMULATION	13
Operating Mode.....	13
Minimum Output Pulse	14
Conversion To Code 39	15
Overflow	15
Output Level	16
Idle Level	16

DATA FORMAT	18
Code Identifier	19
Custom Code Identifier	19
Header	20
Terminator	21
READING PARAMETERS	23
Trigger Type	23
Trigger Signal	23
Trigger-Off Timeout	24
Flash Mode	24
Reads Per Cycle	25
Safety Time	26
Beeper Intensity	27
Beeper Tone	27
Standby	28
DECODING PARAMETERS	29
Overflow Control	29
Interdigit Control	29
CODE SELECTION	30
EAN/UPC Family	30
2/5 Family	34
Code 39 Family	37
Code 128 Family	40
Code 93	40
Codabar Family	41
HARDWARE RESET	43
APPENDIX A CUSTOM CODE IDENTIFIER TABLE	44
APPENDIX B HEX AND NUMERIC TABLE	46

HOW TO USE THIS MANUAL

All products are supplied with their own Quick Reference Manual which provides connection diagrams, basic application parameter settings, default values, and specific technical features.

You can use either your reader's Quick Reference Manual or this Manual for initial configuration in order to set the default values and select the interface for your application.

This manual can be used for complete setup and configuration of your reader.

- **To use this manual for initial setup:**

- 1) Read the Reset Factory Default code on page 2.
- 2) Choose the correct interface selection code at the beginning of one of the following sections:

RS232	page 3
WEDGE	page 9, 10
Wand Emulation	page 13

according to your application.

If you wish to change the default settings, this manual provides complete configuration of your reader in an easy way.

- **To configure your reader:**

- 1) Read the Enter Configuration code ONCE, available at the top of each page of configuration.
- 2) Modify the desired parameters in one or more sections following the procedures given for each group.
- 3) Read the Exit and Save Configuration code ONCE, available at the bottom of each page of configuration.

Reference notes describing the operation of the more complex parameters are written below the specific parameters.

An alternative configuration method is provided by sending the command strings (in the box next to each code) using the RS232 interface. This method is particularly useful when many readers need to be configured with the same settings. Batch files containing the desired parameter settings can be prepared to configure readers quickly and easily.

When this method is used, the programming sequence format is the following:

\$+*Command*\$-CR

- \$+** = Enter configuration environment
- Command*** = Character sequence shown in the boxes next to each code
- \$-** = Exit and Save configuration
- CR** = Carriage return character (0D Hex.)

Example:

Multiple command programming sequence:

\$+EB2BM1AA0AANCR

- \$+** = Enter configuration environment
- EB2** = Enable AIM Standard Code Identifier
- BM1** = Disable Standby (optimize for reading speed)
- AA0** = Disable EAN/UPC family
- AAN** = Enable UPCA/UPCE with Add on 5 only
- CR** = Carriage return character (0D Hex.)

Each configuration parameter setting removes the condition previously active for that parameter.

NOTE

The reader buffer can contain a maximum of 60 characters. If your programming string goes over this value, you must split it into separate groups and send each group after a delay of at least 3 seconds to give the reader time to empty the buffer and interpret the commands.

INTRODUCTION

This manual provides all the necessary information for complete software configuration of your CCD reader.

This product contains a built-in decoder and multi-standard interface.

It is designed for use in a wide variety of environments including **commercial**, **office automation** and **retail** applications where large quantities of information need to be collected rapidly, easily and reliably.

STATUS INDICATORS

The reader has two indicators, LED and beeper. They signal several operating conditions, which are described in the tables below.

Power On

Beeper	Meaning
L L L L	Parameters loaded correctly
H H H H long tones	Parameter loading error, reading or writing error in the non volatile memory
H L H L	Hardware error in EEPROM

Configuration

Beeper	Meaning
H H H H	Correct entry or exit from Configuration mode
L	good read of a command
L L L	command read error

Data Entry

LED	Beeper	Meaning
ON	one beep°	correct read of a code in normal mode
OFF		ready to read a code
	H L H L	output interface not selected
	H L long tones	tx buffer full

H = high tone

L = low tone

° = (user configurable)

RESET FACTORY DEFAULT

Read the code below to set the reader to the factory default values:

Reset Factory Default

\$+\$*



CONFIGURATION

In this manual, the configuration parameters are divided into logical groups making it easy to find the desired function based on its reference group.

The first three groups are for Standard Interface parameter configuration:

- **RS232**
- **WEDGE**
- **WAND EMULATION**

The following groups contain configuration parameters common to all applications:

DATA FORMAT parameters regard the messages sent to the Host system for all interfaces except Wand Emulation.

READING PARAMETERS control various operating modes and indicator status functioning.

DECODING PARAMETERS maintain correct barcode decoding in certain special reading conditions.

CODE SELECTION parameters allow configuration of a personalized mix of codes, code families and their options.

Enter configuration



RS232

RS232 Interface Selection

CD0



Baud Rate

150 baud



CD0

CD1

300 baud



600 baud



CD2

CD3

1200 baud



2400 baud



CD4

CD5

4800 baud




9600 baud



CD6

CD7

19200 baud



Exit configuration



Enter configuration



Parity

none



CC0

CC1

even parity



odd parity



CC2

Data Bits

CA0

7 bits



8 bits



CA1

CA2

9 bits



Stop Bits

1 stop bit



CB0

CB1

2 stop bits



Exit configuration



Enter configuration



Ack/Nack Protocol

enable



CF3

CF0

disable



This parameter sets a transmission protocol in which the Host responds to the reader after every code transmitted. The Host sends an ACK character (06 Hex) in the case of good reception or the NACK character (15 Hex) requesting re-transmission, in the case of bad reception.

Selection of the ACK/NACK protocol automatically disables FIFO buffering.

Handshaking

disable



CE0

CE1

hardware (RTS/CTS)



software (XON/XOFF)




CE2

Exit configuration



Hardware handshaking: (RTS/CTS)


The RTS line is activated by the decoder before transmitting a character. Transmission is possible only if the CTS line (controlled by the Host) is active.



RTS/CTS handshaking

Software handshaking: (XON/XOFF)

During transmission, if the Host sends the XOFF character (13 Hex), the decoder interrupts the transmission with a maximum delay of one character and only resumes when the XON character (11 Hex) is received.



XON/XOFF handshaking

Enter configuration



Inter-Character Delay

delay between characters
transmitted to Host



+ 00 to 99



Read 2 numbers from the table where:

- 00 = DELAY disabled
- 01-99 = DELAY from 1 to 99 milliseconds

FIFO

enable



disable



This parameter determines whether data (barcodes) are buffered on a First In First Out basis allowing faster data collection in certain cases for example when using slow baud rates and/or HW handshaking.

If the FIFO buffering is enabled, codes are collected and sent out on the serial line in the order of acquisition. Up to 185 characters can be collected (buffer full), after which the reader signals an error and discards any further codes until the transmission is restored.

If the FIFO buffering is disabled, each code must be transmitted before another one can be read.

Selection of FIFO buffering automatically disables ACK/NACK protocol.

Exit configuration



Enter configuration



RX Timeout

timeout control
in reception from Host CL + 00 to 99



Read 2 numbers from the table where:

00 = TIMEOUT disabled
01-99 = TIMEOUT from .1 to 9.9 seconds

When the RS232 interface is selected, the Host can be used to configure the reader by sending it command strings (see appendix A).

This parameter can be used to automatically end data reception from the Host after the specified period of time.

If no character is received from the Host, after the timeout expires, any incomplete string (any string not terminated by <CR>) is flushed from the reader buffer.

Exit configuration



Enter configuration



WEDGE

WEDGE Interface Selections

IBM AT or PS/2 PCs




CP500

CP503

IBM XT




PC Notebook



CP505

CP506

IBM SURE1



IBM Terminal 3153



CP504

Exit configuration



Enter configuration



WEDGE Interface Selections

IBM Terminals:

To select the interface for IBM Terminals, read the correct KEY TRANSMISSION code. Select the KEYBOARD TYPE if necessary (default = advanced keyboard).

IBM TERMINALS KEY TRANSMISSION

make-only keyboard

CP502



CP501

make-break keyboard



IBM TERMINALS KEYBOARD TYPE

advanced keyboard

FK1



FK0

typewriter keyboard



Exit configuration



Enter configuration



Keyboard Nationality

English



FJ4

FJ2

French



German



FJ3

FJ1

Italian



Swedish



FJ5

FJ0

USA



Spanish



FJ6

FJ7

Belgian



Exit configuration



Enter configuration



Caps Lock

caps lock OFF



FE0

FE1

caps lock ON



Select the appropriate code to match your keyboard caps lock status.

Note: For **PC Notebook** interface selections, the caps lock status is automatically recognized, therefore this command is not necessary.

Inter-Character Delay

delay between characters
transmitted to Host

CK

+ 00 to 99



Read 2 numbers from the table where:

- 00 = DELAY disabled
- 01-99 = DELAY from 1 to 99 milliseconds

Inter-Code Delay

delay between codes
transmitted to Host

FG

+ 00 to 99



Read 2 numbers from the table where:

- 00 = DELAY disabled
- 01-99 = DELAY from 1 to 99 milliseconds

Exit configuration



Enter configuration



WAND EMULATION

Wand Emulation Interface Selection

CP6




Operating Mode

The operating mode parameters are complete commands and do not require reading the Enter and Exit configuration codes.

interpret mode

\$]



Interprets commands without
sending them to the decoder

transparent mode

\$[



Sends commands to the decoder
without interpreting them

Exit configuration





Minimum Output Pulse

200 μ s

DG0

DG1

400 μ s600 μ s

DG2

DG3

800 μ s

1 ms



DG4

DG5

1.2 ms



This parameter sets the duration of the output pulse corresponding to the narrowest element in the barcode. In this way the code resolution is controlled by the signal sent to the decoder, independently of the physical resolution of the code read.

The shortest pulse (200 μ s) corresponds to a high resolution code emulation and therefore a shorter transfer speed to the decoder (for decoders able to work on high resolution codes). Likewise, longer pulses correspond to low resolution code emulation and therefore a longer transfer time to the decoder.



Enter configuration



Conversion To Code 39

disable

DA0



Transmits all codes
in their original format

DA1

enable



Converts all codes read
into Code 39 format

Overflow

narrow

DH0



DH1

medium



wide

DH2



This parameter generates a white space before the first bar and after the last bar of the code. The selections are as follows:

- narrow = space 10 times the minimum output pulse.
- medium = space 20 times the minimum output pulse.
- wide = space 30 times the minimum output pulse.

Exit configuration



Enter configuration



Output Level

normal

DD0



(white = logic level 0)

DD1

inverted



(white = logic level 1)

Idle Level

normal

DE0



(black level)

DE1

inverted




(white level)

Exit configuration



The following state diagrams describe the different output and idle level combinations for Wand emulation:



Output and Idle Levels

DATA FORMAT

CODE IDENTIFIER TABLE			
CODE	AIM STANDARD	CUSTOM	
		Default	User Defined
2/5 interleaved] l y	N	
2/5 industrial] X y	P	
2/5 normal 5 bars] S y	O	
2/5 matrix 3 bars] X y	Q	
EAN 8] E 4	A	
EAN 13] E 0	B	
UPC A] X y	C	
UPC E] X y	D	
EAN 8 with 2 ADD ON] E 5	J	
EAN 8 with 5 ADD ON] E 6	K	
EAN 13 with 2 ADD ON] E 1	L	
EAN 13 with 5 ADD ON] E 2	M	
UPC A with 2 ADD ON] X y	F	
UPC A with 5 ADD ON] X y	G	
UPC E with 2 ADD ON] X y	H	
UPC E with 5 ADD ON] X y	I	
Code 39] A y	V	
Code 39 Full ASCII] A y	W	
CODABAR] F y	R	
ABC CODABAR] X y	S	
Code 128] C 0	T	
EAN 128] C 1	k	
Code 93] G y	U	
CIP/39] X y	Y	
CIP/HR] X y	e	
Code 32] X y	X	

AIM standard identifiers are not defined for all codes: the X identifier is assigned to the code for which the standard is not defined. The y value depends on the selected options (check digit tested or not, check digit tx or not, etc.).

For Custom Code Identifiers, 1 or 2 identifier characters can be defined for each code type. If only 1 identifier character is required, the second character must be selected as **FF** (disabled).

The code identifier can be singly disabled for any code by simply selecting **FF** as the first identifier character.

Write in the User Defined Custom character identifiers in the table above for your records.

Enter configuration



Code Identifier

disable



EB0

EB3

custom



AIM standard



EB2

Custom Code Identifier

define custom code identifier(s)

EH



- ① Read the above code.
(This sets the Custom Code Identifier default values, see table on previous page).
- ② Select the code type from the code table in Appendix A for the identifier you want to change.
- ③ You can define 1 or 2 identifier characters for each code type. If only 1 identifier character is required, the second character must be selected as **FF** (disabled). Read the hexadecimal value (Appendix B) corresponding to the character(s) you want to define as identifiers for the code selected in step ②: valid characters are in the range **00-7F**.

EXAMPLE: To define Code 39 Code Identifier = @

define custom code identifier(s)

Read



+ Code 39 + 40 + FF
(Appendix A)

Exit configuration



Enter configuration



Header

no header

EA00



RS232 Hex values from 00 to 7F
WEDGE Hex values from 00 to 99
Appendix B

one character header

EA01

+ 1 Hex. value



two character header

EA02

+ 2 Hex. values



three character header

EA03

+ 3 Hex. values



four character header

EA04

+ 4 Hex. values



Exit configuration



Enter configuration



Terminator

no terminator

EA10



RS232 Hex values from 00 to 7F
WEDGE Hex values from 00 to 99
Appendix B

one character terminator

EA11 + 1 Hex. value



two character terminator

EA12 + 2 Hex. values



three character terminator

EA13 + 3 Hex. values



four character terminator

EA14 + 4 Hex. values



Exit configuration



The header/terminator selection is not effected by the reading of the reset factory default code. In fact, header and terminator default values depend on the interface selection:

RS232: no header, terminator CR-LF
 WEDGE: no header, terminator ENTER

These default values are always restored through the reading of RS232 or WEDGE interface selection codes, see pages 3, 9-10 or the relative Quick Reference Manual.

For the WEDGE interface, the following extended keyboard values can also be configured:

EXTENDED KEYBOARD TO HEX CONVERSION TABLE			
	IBM AT	IBM 3153	IBM XT
HEX	KEY	KEY	KEY
83	ENTER	ENTER	FIELD EXIT
84	TAB	TAB	TAB
85	F1	F1	F1
86	F2	F2	F2
87	F3	F3	F3
88	F4	F4	F4
89	F5	F5	F5
8A	F6	F6	F6
8B	F7	F7	F7
8C	F8	F8	F8
8D	F9	F9	F9
8E	F10	F10	F10
8F	F11	ESC	F11
90	F12	BACKSPACE	F12
91	HOME	HOME	ENTER
92	END	END	RESET
93	PG UP	PG UP	INSERT
94	PG DOWN	PG DOWN	DELETE
95	↑	↑	FIELD -
96	↓	↓	FIELD +
97	←	←	ENTER (Paddle)
98	→	→	PRINT
99	ESC	ESC	
9A	CTRL (Right)	CTRL (Right)	

Enter configuration



READING PARAMETERS

Trigger Type

hardware trigger

BK1



Restores Trigger mode

software trigger

BK0



Enables "FLASH" mode

Trigger Signal

trigger active level

BA0



trigger active pulse

BA1



Trigger signal is useful to determine the modality of the reader ON state when hardware trigger is selected:

- trigger level: the reader goes ON when the trigger is pressed and goes OFF when it is released
- trigger pulse: the reader goes ON at the first trigger press and goes OFF only at a second press

Exit configuration



Enter configuration



Trigger-Off Timeout

trigger-off timeout



+ 00 to 99



Read 2 numbers in the range 00-99:

00 = disables the trigger-off timeout

01-99 = corresponds to a max. 99 sec. delay after the trigger press to allow the reader to turn off automatically.

The timeout is useful when hardware trigger type is selected. When a timeout is selected, the reader (if not decoding) turns OFF automatically after the desired period of time.

Flash Mode

"FLASH" ON duration



+ 01 to 99



"FLASH" OFF duration



+ 01 to 99



Read 2 numbers in the range 01-99:

01 to 99 = from .1 to 9.9 seconds.

Exit configuration



Enter configuration



Reads Per Cycle

one read per cycle

BC0



multiple reads per cycle

BC1



In general, a **reading cycle** corresponds to the ON + OFF times of a reader. The resulting effects of this parameter on code reading depend on other related configuration conditions. Here are the definitions of ON and OFF times.

- ❑ For readers which operate in FLASH MODE or readers using the *software trigger* parameter, a reading cycle corresponds to the *flash on* + *flash off* times. Code reading takes place during the *flash on* time.
- ❑ For readers using the *hardware trigger* parameter, a reading cycle corresponds to a trigger press (ON) + one of the following OFF conditions:
 - trigger release (for *trigger active level*)
 - a second trigger press (for *trigger active pulse*)
 - *trigger-off timeout*.

When **one read per cycle** is selected, the reader decodes only one code during the ON period and immediately turns OFF the reader. It is only possible to read another code when the next ON time occurs.

In **multiple reads per cycle**, the reader decodes a code during the ON period. The *flash on* or the *trigger-off timeout* period is immediately reset after each read and therefore extended. If another code is decoded before the reset *flash on* or *timeout* period expires, the *flash on* or *timeout* is

Exit configuration



Enter configuration



again reset and the effect is that the reader remains ON, decoding codes until the *flash on* or *timeout* period expires.

The Safety Time parameter should be used in this case to avoid unwanted multiple reading of the same code.

Safety Time

safety time

BE + 00 to 99



Limits same code consecutive reading

Read 2 numbers in the range 00-99:

00 = no same code consecutive reading until reader is removed (no decoding) for at least 400 ms.

01 to 99 = timeout from .1 to 9.9 seconds before a consecutive read on same code.

Safety time prevents the reader from immediately decoding the same code more than once. Same code consecutive reading can be disabled requiring the reader to be removed from the code (no decoding) for at least 400 ms, or a timeout can be set up to 9.9 seconds before the decoder will accept the same code. Reading is immediate if the code changes.

Exit configuration



Enter configuration



Beeper Intensity

beeper off



BG0

BG1

low intensity



medium intensity



BG2


BG3

high intensity



Beeper Tone

tone 1



BH0

BH1

tone 2



tone 3



BH2

BH3

tone 4



Exit configuration



Enter configuration



Standby

enable



BM0

optimize for low power consumption

disable



BM1

optimize for reading speed

If this command is enabled, part of the CCD circuitry shuts down (Standby), in order to optimize low power consumption when not reading. When the trigger is pressed this circuitry powers up. This mode causes a minor delay before the reader is ready, ranging from a few milliseconds to a few tenths of a second (depending on the reader).

Exit configuration



Enter configuration



DECODING PARAMETERS

Overflow Control

disable



AW1

enable



AW0

The overflow control parameter can be disabled when decoding codes printed on small surfaces, which don't allow the use of an overflow space.

This command does not effect code families 2/5, Code 128 and Code 93.

Interdigit Control

disable



AV0

enable



AV1

The interdigit control parameter verifies the interdigit spacing for code families Code 39 and Codabar.

Exit configuration



Enter configuration



CODE SELECTION

DISABLES ALL CODE FAMILIES

AZ0



Note:

The reader allows up to 5 code selections.

All SINGLE code selections are underlined and in bold.

EAN/UPC Family

disables the family

AA0



- ① Read the desired family code

Note:

Since the EAN/UPC without ADD ON code selection is enabled by default, to correctly enable another selection from this family, first disable the family.

EAN 8/EAN 13/UPC A/UPC E
with and without ADD ON

AA8



Exit configuration



Enter configuration



Without Add On

EAN 8/EAN 13/

UPC A/UPC E



AA1

AA3

EAN 8/EAN 13



UPC A/UPC E



AA4

With Add On 2 And 5

AA5

EAN 8/EAN 13/

UPC A/UPC E



EAN 8/EAN 13



AA6

AA7

UPC A/UPC E



Exit configuration



Enter configuration



With Add On 5 Only

EAN 8/EAN 13



AAL

AAN

UPC A/UPC E



With Add On 2 Only

EAN 8/EAN 13



AAK

AAM

UPC A/UPC E



EAN/UPC Check Digit Tx Selections

For each code type in this family you can choose to transmit the check digit or not

CHECK DIGIT TRANSMISSION

EAN 8



AAG1

AAH1

EAN 13



UPC A



AAI1

AAJ1

UPC E



Exit configuration



Enter configuration



NO CHECK DIGIT TRANSMISSION

EAN 8



AAG0

UPC A



AAI0

AAH0

EAN 13



AAJ0

UPC E



Conversion Options

UPC E to UPC A



AAA

AAB

UPC E to EAN 13



UPC A to EAN 13



AAC

AAD

EAN 8 to EAN 13



Exit configuration



Enter configuration



2/5 Family

disables the family

AC0



1. Read one check digit option from the desired family code.
2. Read **4** numbers from Appendix B for the code length where:
First 2 digits = minimum code length.
Second 2 digits = maximum code length.

The maximum code length is 55 characters.

The minimum code length must always be less than or equal to the maximum.

Examples:

0155 = variable from 1 to 55 digits in the code.

1010 = 10 digit code length only.

Interleaved 2/5

AC11

+ 4 numbers



no check digit control

AC12


+ 4 numbers



check digit control and transmission

AC13

+ 4 numbers



check digit control without transmission

Exit configuration



Enter configuration



Normal 2/5 (5 Bars)

AC21

+ 4 numbers



no check digit control

AC22

+ 4 numbers



check digit control and transmission

AC23

+ 4 numbers



check digit control without transmission

Industrial 2/5 (IATA)

AC31

+ 4 numbers



no check digit control

AC32

+ 4 numbers



check digit control and transmission

AC33

+ 4 numbers



check digit control without transmission

Exit configuration



Enter configuration



Matrix 2/5 (3 Bars)



no check digit control

AC41 + 4 numbers



check digit control and transmission

AC42 + 4 numbers



check digit control without transmission

AC43 + 4 numbers

The pharmaceutical code below is part of the 2/5 family but has no check digit nor code length selections.

Code CIP/HR



French pharmaceutical code

AC5

Exit configuration



Enter configuration



Code 39 Family

disables the family

AB0



Read one check digit option from the desired family code.

Standard Code 39

AB11



no check digit control

AB12



check digit control and transmission

AB13



check digit control without transmission

Exit configuration



Enter configuration



Full ASCII Code 39

AB21



no check digit control

AB22



check digit control and transmission

AB23



check digit control without transmission

The pharmaceutical codes below are part of the Code 39 family but have no check digit selections.

Code CIP39

AB3



French pharmaceutical code

Code 32

AB4



Italian pharmaceutical code

Exit configuration



Enter configuration



Code 39 CODE LENGTH (optional)

The code length selection is valid for the entire Code 39 family

Read the code below + 4 numbers for the code length where:

First 2 digits = minimum code length.

Second 2 digits = maximum code length.

set code length



AB*

The maximum code length is 32 characters. The minimum code length must always be less than or equal to the maximum.

Examples: **0132** = variable from 1 to 32 digits in the code. **010** = 10 digit code length only.

Exit configuration



Enter configuration



Code 128 Family

disables the family



A10

Read the desired family code.

Code 128



A11

control without transmission
of check digit

EAN 128



A12

control without transmission
of check digit

Code 93

disables the code



AK0

Code 93



AK1

control without transmission
of check digit

Exit configuration



Enter configuration



Codabar Family

disables the family


ADO



Read the desired equality control code.

Standard Codabar

AD111



no start/stop character
equality control nor transmission

AD112



no start/stop character
equality control but transmission

AD121



start/stop character
equality control but no transmission

AD122



start/stop character
equality control and transmission

Codabar ABC

AD212



no start/stop character equality control but transmission

Exit configuration



Enter configuration



Codabar CODE LENGTH (optional)

The code length selection is valid for the entire Codabar family

Read the code below + 4 numbers for the code length where:

First 2 digits = minimum code length.

Second 2 digits = maximum code length.

set code length

AD*



The maximum code length is 44 characters. The minimum code length must always be less than or equal to the maximum.

Examples: **0144** = variable from 1 to 44 digits in the code. **1010** = 10 digit code length only.

START/STOP CHARACTER CASE

The start/stop character case selections below are valid for the entire Codabar family:

lower case start/stop characters

ADAO



upper case start/stop characters

ADA1



Exit configuration



HARDWARE RESET

If your reader does not work properly after configuration, read the code below and then read the reset factory default code and the interface selection code for your application.

Hardware Reset



APPENDIX A CUSTOM CODE IDENTIFIER TABLE

2/5 Interleaved



2/5 Industrial



2/5 normal 5 bars



2/5 matrix 3 bars



EAN 8



EAN 13



UPC A



UPC E



EAN 8 with 2 ADD ON



EAN 8 with 5 ADD ON



EAN 13 with 2 ADD ON



EAN 13 with 5 ADD ON



UPC A with 2 ADD ON



UPC A with 5 ADD ON



UPC E with 5 ADD ON



Code 39 Full ASCII



ABC CODABAR



EAN 128



CIP/39



Code 32



UPC E with 2 ADD ON



Code 39




CODABAR



Code 128



Code 93



CIP/HR



APPENDIX B HEX AND NUMERIC TABLE

CHARACTER TO HEX CONVERSION TABLE					
Char	hex	char	hex	char	hex
NUL	00	*	2A	U	55
SOH	01	+	2B	V	56
STX	02	,	2C	W	57
ETX	03	-	2D	X	58
EOT	04	.	2E	Y	59
ENQ	05	/	2F	Z	5A
ACK	06	0	30	[5B
BEL	07	1	31	\	5C
BS	08	2	32]	5D
HT	09	3	33	^	5E
LF	0A	4	34	_	5F
VT	0B	5	35	`	60
FF	0C	6	36	a	61
CR	0D	7	37	b	62
SO	0E	8	38	c	63
SI	0F	9	39	d	64
DLE	10	:	3A	e	65
DC1	11	;	3B	f	66
DC2	12	<	3C	g	67
DC3	13	=	3D	h	68
DC4	14	>	3E	i	69
NAK	15	?	3F	j	6A
SYN	16	@	40	k	6B
ETB	17	A	41	l	6C
CAN	18	B	42	m	6D
EM	19	C	43	n	6E
SUB	1A	D	44	o	6F
ESC	1B	E	45	p	70
FS	1C	F	46	q	71
GS	1D	G	47	r	72
RS	1E	H	48	s	73
US	1F	I	49	t	74
SPACE	20	J	4A	u	75
!	21	K	4B	v	76
"	22	L	4C	w	77
#	23	M	4D	x	78
\$	24	N	4E	y	79
%	25	O	4F	z	7A
&	26	P	50	{	7B
'	27	Q	51		7C
(28	R	52	}	7D
)	29	S	53	~	7E
		T	54	DEL	7F



0



1



2



3



4



5



6



7



8



9



A



B



C



D



E




F



10



11



12



90ACC1740